



## MEASURING INSTRUCTIONS FOR UPG – Unclear Panel Guard (Vertical Pump Panel Guard)



### Guard Type: UPG

#### Complete these forms in their entirety:

- “Uniguard Customers Name” is who is purchasing the guard from us.
- “Uniguard Customers Contact” information allows us to contact the correct person if questions arise during production
- “Equipment Mfg. & Model” allows us to capture information for future production.
- “Quantity” needed to quote
- “Equipment Numbers” allows the customer to know where the guard is to be installed within their facility

#### Things to consider:

- Will this be attached by drilling and tapping the bearing frame or with our mounting brackets?
- Will the customer need to modify in the field for a seal flush line?

#### Options:

- Unclear material for visual inspection

### Measuring Instructions

1. Measure and record the opening length. Determine the amount of needed overhang above and below the opening and record as the overall length.





## MEASURING INSTRUCTIONS FOR UPG – Uniclear Panel Guard (Vertical Pump Panel Guard)



2. Measure and record the opening width. Determine the amount of needed overhand on each side and record as the overall width. Based on the design, you may need to make roughly a 45-degree outward bend to accommodate gussets that the guard can be attached in lieu of our mounting brackets.



3. Measure the housing thickness if you plan on utilizing our mounting brackets that slide under the housing to affix the guard to the bearing frame.

